



ACCESSORY KIT

Set of accessories containing four pens, five magnets, a spray bottle for cleaning with water, a board eraser, three felt pads, a microfibre cloth and four magnetic holders for each individual pen.

- 4 felt-tip pens + 4 pen holders
- 1 board eraser + 3 spare felt pads
- 5 magnets
- 1 spray bottle for water
- 1 microfibre cloth

Article number	Name	Weight kg
40445	Accessory kit Black	1
40446	Accessory kit Grey New	1



40445



40446

STARTSET BIRCH & CORK

Set of accessories made from cork or birch. The kit contains four pens, five magnets, a spray bottle for cleaning with water, a board eraser, five spare felt pads, a microfibre cloth and four magnetic holders for each individual pen. Designed by Matti Klenell.

4 felt-tip pens + 4 pen holders
1 board eraser + 5 spare felt pads
5 magnets
1 spray bottle for water
1 microfibre cloth

Article number	Name	Weight kg
40245-B	Startset Birch, extra strong magnets	1
40245-C	Startset Cork, extra strong magnets	1
40245-SC	Startset Cork Black, extra strong magnets	1



PENS & PENHOLDERS

Article number	Name	Weight kg
40290	Felt-tip pens 4/pack (black, red, green & blue ink)	0,1
40294	Felt-tip pens 4/pack (black ink)	0,1
40293	Felt-tip pens Grey 4/pack (black ink)	New 0,1
40264	Felt-tip pens 4/ pack (green, pink, yellow, orange)	0,1
40263	Pen for glass boards (white)	0,1
40278	Magnetic pen holder Black single 4/pack, whiteboards & glass boards	0,1
40279	Magnetic pen holder Grey single 4/pack, whiteboards & glass boards	New 0,1

BOARD ERASER & FELT SETS

Article number	Name	Weight kg
40459	Board eraser, black, magnetic	0,5
40458	Board eraser, grey, magnetic	New 0,5
40460	Felt set for board eraser 40459, 10pcs	0,1
40360	Felt set for board eraser 40359, 5pcs	0,1
40262	Micro fibre cloth (5pcs)	0,1
40444	Bottle holder magnetic	New 0,1
40044	Cleaning liquid 0,25l	0,3