

Framery One
User Instructions

English Version 1.2 Tampere, Finland 21.9.2021

## **Contents**

1	Important safety and product instructions	5
	1.1 Preface	
	1.2 Product information	
	1.3 Copyright	
	1.4 Manual contents	
	1.5 Intended use	
	1.5.1 Non-conventional use	
	1.5.2 Ambient conditions for use	
	1.6 Warning, information and safety symbols in this manual	
	1.7 Main safety risks related to the installation, maintenance, disassembly, and	
	use of the product	
	1.7.1 Installation, maintenance, and disassembly	
	1.7.2 Electrical safety	
	1.7.3 Fire safety	
	1.7.4 Use	
	1.7.5 Moving the product on wheels (optional)	10
	1.7.6 Radio frequency	
	1.8 Location of product markings	12
	1.9 Electrical system	14
2	Entering the pod	15
3	Adjusting the chair	16
4	Adjusting the electric height-adjustable table	17
5	Connecting electrical equipment	18
6	Using the wireless charger (optional)	19
7	Adjusting the fans	20
8	Adjusting the lights	21
9	Exiting the pod	22

Framery One

## 1 Important safety and product instructions

### 1.1 Preface

This instruction manual describes the use of the product. Everyone involved in using the product must read and understand the contents of the user and safety instructions.

This instruction manual gives you necessary information for the correct use.

#### 1.2 Product information

The information in this manual corresponds to the product at the time of delivery. All information included in this manual is valid at the time of publication.

### 1.3 Copyright

This document must not be copied, presented, or delivered to a third party without explicit permission from Framery. The use of this document for any purpose other than those allowed by Framery is prohibited. Framery reserves the right to change the instructions related to the product without separate notice.

#### 1.4 Manual contents

The user instructions contain the following information:

- General information about the purpose and content of the instructions
- · Information related to safety
- User instructions

#### 1.5 Intended use

The Framery One is a pod intended for short term indoor commercial and household use by one (1) person at a time.



### Warning:

WARNING -To reduce the risk of burns, fire, electric shock, or injury to persons:

Use this product only for its intended use as described in the user instructions. Do not use attachments not recommended by the manufacturer.

### 1.5.1 Non-conventional use

Any use or maintenance of the product that is not specifically allowed in the installation, maintenance, troubleshooting or user instructions is prohibited, including the following:

- Installation, maintenance or disassembly of the pod without reading and understanding the instructions for those actions
- · Use of the pod beyond the limits of use
- Making alterations to the pod

- Using the pod in spite of obvious defects or damage
- Using the pod outdoors or in conditions where the temperature or air quality is not safe
- · Climbing on top of the product or placing any load on the roof of the product
- · Smoking in the pod

#### 1.5.2 Ambient conditions for use

The pod is intended to be used in the following conditions:

- Ambient temperature: +15°C ... +30°C (59°F ... 86°F)
- Humidity: max. 50%
- Sufficient air quality surrounding the product

### 1.6 Warning, information and safety symbols in this manual

The warnings in this manual have been divided into the following two categories:

- The term "DANGER" indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- The term "WARNING" indicates a hazardous situation which, if not avoided, could result in death or injury.

The safety symbols found in this manual may also be posted on the product. All personnel who install, disassemble, perform maintenance or use the product are to be familiar with and observe all safety symbols, labels, and instructions about the action they are performing.

Table 1: Hazard



An exclamation point symbol inside a colored triangle indicates a hazardous situation.



### Table 2: Mandatory action



A white symbol inside a colored circle indicates an action that must be taken to avoid a hazardous situation.

#### Table 3: Prohibited action



A ring with a diagonal bar indicates an action that is not allowed.

# 1.7 Main safety risks related to the installation, maintenance, disassembly, and use of the product



#### 1.7.1 Installation, maintenance, and disassembly



#### **WARNING!**

To reduce the risk of burns, fire, electric shock, or injury to persons, obey the following:



Use cut resistant safety gloves during the installation, maintenance or disassembly of the product.



Use steel toed safety boots during the installation, maintenance or disassembly of the product.



Read and understand the instructions and plan your work beforehand.



Obey all local rules and regulations regarding workplace safety.



Keep the work site tidy and free from debris throughout the installation, maintenance or disassembly process.



Do not climb on top of the product or place any load on the roof of the product.



Do not move the finished product by pushing if the optional wheels are not engaged.

The product is very heavy. Moving the product after installation without engaging the optional wheels is not allowed.

### 1.7.2 Electrical safety

Input for the electrical system: 100-240 VAC (10 A) 50-60 Hz

The maximum load for the electrical system is 6.6 A.



#### DANGER!

To reduce the risk electric shock, obey the following:



Disconnect the power cord from the power outlet before starting any cleaning, maintenance or disassembly procedures.

The power cord serves as a power disconnect device for pluggable equipment. The power outlet shall be located near the equipment and shall be easily accessible.



#### WARNING!


To reduce the risk of burns, fire, electric shock, or injury to persons, obey the following:



Connect the power cord to a properly grounded outlet only.



This product is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated in the figure below. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.





Keep the power cord of the product away from heated surfaces.



Do not use the pod if you notice any defects or damage to the electrical equipment.



Do not connect any extension cords to the power outlet(s) of the product.

### 1.7.3 Fire safety



#### WARNING!

To reduce the risk of burns, fire, electric shock, or injury to persons, obey the following:



If safely possible to perform, disconnect the power cord from the power outlet if there is a fire inside the product.

The power cord serves as a power disconnect device for pluggable equipment. The power outlet shall be located near the equipment and shall be easily accessible.

Fire safety end devices (alarms, sprinklers etc.) can also be installed inside the pods (instructions available upon request). The need for end devices inside the pod is always determined by the applicable local authorities.



#### 1.7.4 Use



### Warning:

WARNING -To reduce the risk of burns, fire, electric shock, or injury to persons:

If the product is anticipated to be used in places where children under the age of 8 and people with cognitive disabilities are present, use must be supervised at all times.

The maximum load for the Framery One adjustable table is 50 kg (110 lbs)

The maximum load for the Framery One chair is 136 kg (300 lbs)



#### **WARNING!**

To reduce the risk of burns, fire, electric shock, or injury to persons, obey the following:



Read and understand the user instructions before using the product.



Note: The following statement applies to use in Japan.

This equipment is not suitable for use in locations where children are likely to be present.



Note: The following statements apply to use in all other countries.

Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.

Keep children away from extended foot support (or other similar parts).



Risk of injury! Keep hands and other body parts clear of the side edges of the table when raising or lowering the electrically adjustable table top. This applies to all Framery pods with an electric adjustable table.



Do not use the product if the surrounding conditions are in any way hazardous; the air circulating inside the pod is derived from the surrounding space.



Do not use the product if the ventilation is not functioning.



Do not use the product if the ventilation channels are blocked. Keep the ventilation channels free of lint, hair, and the like.



Do not use the pod if you notice any defects in the electrical equipment or if the product is not working properly. Disconnect the power cord from the power outlet and contact your local dealer or the manufacturer immediately.

0	Do not drop or insert any object into any opening if not specifically instructed to do so in this manual.
0	Do not use outdoors.
0	Do not use where aerosol (spray) products are being used or where oxygen is being administered.
0	Do not climb on top of the product or place any load on the roof of the product.
0	Do not lean against the product.
0	Do not smoke inside the product.
	Do not obstruct the view through the front and back glasses by posting signs, decorations, or by installing blinds or draperies that would prevent occupants from seeing the visible alarm appliances located in the structure where the pod is installed.

### 1.7.5 Moving the product on wheels (optional)



#### WARNING!

The product is very heavy. Moving the product on the wheels requires planning and care. Make sure the product cannot tip over while moving.



Only move the product on even surfaces: no cracks or thresholds over 3 mm (1/8 in) on the intended route.



When moving the product, only push below the vertical middle. Do not tow the product.



Do not enter the product if it is standing on the wheels. It is only allowed to use the wheels for moving the product. Return the full weight of the product onto the leveling feet immediately after relocation and level the floor.

### 1.7.6 Radio frequency

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a



residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Note: Any changes or modifications not expressly approved by Framery Oy could void the user's authority to operate the equipment.

The Control Unit of this Framery Phone Booth is a portable device per FCC 2.093. The FCC labelling and compliance information is electronically available on Control Unit display. The Control Unit is exclusively for use in Framery Phone Booth and not to be integrated to any other device.


The regulatory information can be accessed from the control panel:







## 1.8 Location of product markings



Position	Label	Label text
1.	WARNING! L'AVERTISSEMENT Risk of injury Risque de blessure	WARNING! Risk of injury
	Risk of injury  Maximum table load  110 lbs / 50 kg  110 lbs / 50 kg  110 lbs / 50 kg  Risque de blessure  Polids maximal autorisé  110 lbs / 50 kg (tableau)	Maximum table load 110 lbs / 50 kg
		L'AVERTISSEMENT Risque de blessure
		Poids maximal autorisé 110 lbs / 50 kg (tableau)
2.	WARNING! RISK OF INJURY NOT to be used in locations where children, or people with cognitive disabilities are anticipated to be present and not supervised.  AVERTISSEMENT, RISQUE DE BLESSURE, Ne pas utiliser ees cabines dans des lieux susceptibles d'accueillir des enfants ou deutes souffrant de troubles cognitifs sans surveillance.	WARNING! RISK OF INJURY
		Not to be used in locations where children, or people with cognitive disabilities are anticipated to be present and not supervised.
		AVERTISSEMENT, RISQUE DE BLESSURE,
		Ne pas utiliser ces cabines dans des lieux susceptibles d'accueillir des ensfants ou des adultes souffrant de troubles cognitifs sans surveillance.
3.	FOR US AND CANADA ONLY WARNING — Risk of fire and shock!	FOR US AND CANADA ONLY
	Use only SJT type 16 AWG cord.  AVERTISSEMENT – Risque d'incendie et de choc électrique, Utiliser uniquement un cordon d'alimentation SJT de type 16 AWG.	WARNING - Risk of fire and shock!
		Use only SJT type 16 AWG cord.
		AVERTISSEMENT - Risque d'incendie et de choc électrique, Utiliser uniquement un cordon d'alimentation SJT de type 16 AWG.
4.	Framery  Product / Produit Framery One Input / Entrée 100-240 VAC (10A) 50-60Hz  Manufacture / Fabricant: Framery Oy Web: www.frameryacoustics.com Web: www.frameryacoustics.com Email: info@rameryacoustics.com Made in Finland / Fabriqué en Finland Banchez toujours le produit dans une prise Retention  Manufacture date / Date de fabrication  Manufacture date / Date de fabrication	Framery
		Manufacturer / Fabricant: Framery Oy
		WEB: www.frameryacoustics.com
		Email: info@frameryacoustics.com
		Made in Finland / Fabriqué en Finlande
		Manufacture date / Date de fabrication
		Product / Produit Framery One
		Input / Entrée 100-240 VAC (10 A) 50-60 HZ
		Attention! Always connect the product correctly to a grounded socket to avoid danger for fire or electrical shocks.
		Attention! Branchez toujours le produit dans une prise reliée à la terre pour éviter tout risque d'incendie ou choc électrique.

Position	Label	Label text
5.	Framery Input: 24V DC (4A MAX) Model 8180678 Rev. B S/N:	Framery Ceiling unit Input: 24V DC (4A MAX) Model 8180678 Rev. B S/N:

### **SAVE THESE INSTRUCTIONS**


## 1.9 Electrical system

Framery One, a soundproof office pod for video conferencing, includes a built-in electrical system made by Framery. The model of the system is Supra 12020.




## 2 Entering the pod

- 1. Pull the door open.
- 2. Step into the pod.
- **3.** Pull the door shut.




## 3 Adjusting the chair

- 1. Sit on the chair to determine the possible need for adjustments.
- **2.** To adjust to a lower position, gently pull up on the lever at the side until the correct height is reached.
- **3.** To adjust to a higher position, lighten your weight off the seat and gently pull the lever at the side until the correct height is reached.




## 4 Adjusting the electric height-adjustable table

1. To adjust the table to a lower position, press the right-hand side button on the table handset.




**2.** To adjust the table to a higher position, press the left-hand side button on the table handset.





## 5 Connecting electrical equipment

1. To connect your device to the power outlet, USB-C connector, or LAN connector (optional), connect one end of the cord in question to your device and insert the other end to the corresponding connector in the control panel.




2. To disconnect your device from the power outlet, USB-C connector, or LAN connector (optional), disconnect the cord in question from the connector in the control panel.






## 6 Using the wireless charger (optional)

- 1. To activate wireless charging, place your device (compatible with wireless charging) on top of the wireless charger sticker, located at the left-hand side of the table top.
- 2. To deactivate wireless charging, remove the device.




## 7 Adjusting the fans

- 1. To access the fan controls, press the fan icon on the main menu of the control panel.
- 2. To adjust the level of ventilation, slide the level line up (more ventilation) or down (less ventilation) as needed.
- **3.** To return to the main menu, press the fan icon.



## 8 Adjusting the lights

- 1. To access the light controls, press the light icon on the main menu of the control panel.
- 2. To adjust the lighting, slide the level line up (brighter) or down (less bright) as needed.
- 3. To return to the main menu, press the light icon.



## 9 Exiting the pod

- 1. Push the door open.
- 2. Step out of the pod.
- 3. Push the door shut.







# framery

Framery One User Instructions Patamäenkatu 7 33900 Tampere FINLAND

VAT: FI 23527139