

GEIGER

Taper™ Chair

Seat Height

LOWER RIGHT SIDE OF SEAT



TO RAISE
Take your weight off chair,
lift tab up.

TO LOWER
Lift tab up while seated.

At the proper height, your feet should
rest flat on the floor with upper and
lower leg forming a 90 degree angle.

Forward Tilt

HORIZONTAL TAB ON LEFT FRONT SIDE OF SEAT



TO ENGAGE
Recline and flip lever down.

TO RELEASE
Recline and flip lever up.

Engage forward tilt to support the thigh's
declined posture when performing
intensive tasks, such as keyboarding.

*Note: When using forward seat angle, increase
seat height slightly for added comfort.*

Harmonic™ Tilt Tension

KNOB BELOW RIGHT FRONT SIDE OF SEAT



TO INCREASE
Turn knob clockwise.

TO DECREASE
Turn knob counterclockwise.

Set the tilt tension to control the
resistance you feel when reclining.

Tilt Limiter

VERTICAL TAB ON LEFT FRONT SIDE OF SEAT



TO ENGAGE
Recline and move lever up to define
the limit of recline.

TO RELEASE
Lean forward and press lever back.

*Engage the tilt limiter when you want to sit in
an upright or partially reclined position.*