


Ax 1



Bx 1




Cx 2




Click C into both top and bottom frame's slot.

①



Hold **A** straight with the help of another person.
Starting from the bottom to the top, press click **A** into the frame's slot.

②



For more detail please check the following
assembly video:


<http://vimeo.com/69549861>



HAY

Fix the other side of **A** to the frame by press click **A** into **C**

③



Press click **B** into **A**

⑤

